



**TOPPERS (G-02-69, G-02-72, G-02-317 and G-02-329)**

Control panel styling and appearance can be changed by adding an auxiliary "Topper" button. Standard color is black, but it is available in other colors. Be certain to allow enough clearance between top of switch and bottom of Topper by selecting correct switch button height.




BUTTON HEIGHT	DIM. "C"
.344 (8.74)	.115 (2.92)
.406 (10.31)	.177 (4.50)
.500 (12.70)	.271 (6.88)
.625 (15.88)	.396 (10.06)
.750 (19.05)	.521 (13.23)




BUTTON HEIGHT	DIM. "C"
.344 (8.74)	.138 (3.51)
.406 (10.31)	.200 (5.08)
.500 (12.70)	.296 (7.52)
.625 (15.88)	.419 (10.64)
.750 (19.05)	.544 (13.82)

*For use with .278" button width only.*



*For use with .312" button width only.*

BUTTON HEIGHT	DIM. "C"
.344 (8.74)	---
.406 (10.31)	---
.625 (15.88)	.126 (3.20)
.750 (19.05)	.251 (6.38)



*For use with .312" button specify G-02-72.*

*For use with .278" button specify G-02-72-6.*

RoHS Compliant

**CW INDUSTRIES**  
Southampton, Pa. 18966  
Tel 215.355.7080/www.cwind.com

Date Drawn: 10-20-15

Rev. 0

Unit: mm

Checked By: *G. GULD*

Title:  
**ACTUATOR TOPPERS**

CW P/N: